




EDILOCK Group Ltd.

www.edilock-bg.com

www.vag-info.com

UNIVERSAL JULIE EMULATOR




Universal Julie emulator includes

34 immo and 18 seat occupancy sensor programs

- no jumpers – diagnostic mode - it flashes every second
- EDC15, EDC16 if used before – does not flash
- adjusting to the ECU – flashing 0,1 sec
- after adjusting it lights constantly and blinks every other second

Use

1. VW without CAN



Connection instructions – see manual for
VW without CAN

2. VW Hitachi



Connection instructions – see manual for
VW - Hitachi


3. VW – Valve Code



Connection instructions – see manual for


VW - Valve Code

4. VW EDC15 immo OFF (single use)




Connection instructions – see manual for
VW EDC15 immo OFF - ON (single use)

5. VW EDC15 immo ON (single use)




Connection instructions – see manual for
VW EDC15 immo OFF - ON (single use)

6. VW EDC16 K - LINE immo OFF (single use)



Connection instructions – see manual for
VW EDC16 K-LINE immo OFF - ON (single use)

7. VW EDC16 K – LINE immo ON (single use)




Connection instructions – see manual for
VW EDC16 K-LINE immo OFF - ON (single use)

8. VW EDC16 with CAN 1.9 2.0 TDI immo OFF (single use)



Connection instructions – see manual for
VW EDC16 CAN 1.9 2.0 TDI immo OFF – ON (single use)

9. VW EDC16 with CAN 1.9 2.0 TDI immo ON (single use)




Connection instructions – see manual for
VW EDC16 CAN 1.9 2.0 TDI immo OFF - ON (single use)

10. VW EDC16 with CAN 2.7 3.0 TDI immo OFF (single use)



Connection instructions – see manual for
VW EDC16 CAN 2.7 3.0 TDI immo OFF - ON (single use)

11. VW EDC16 with CAN 2.7 3.0 TDI immo ON (single use)



Connection instructions – see manual for
VW EDC16 CAN 2.7 3.0 TDI immo OFF - ON (single use)

12. VW ME7 immo OFF (single use)




Connection instructions – see manual for
VW ME7 immo OFF - ON (single use)

13. VW ME7 immo ON (single use)



Connection instructions – see manual for
VW ME7 immo OFF - ON (single use)


14. Citroen, Peugeot CAN



Connection instructions – see manual for Citroen, Peugeot CAN

15. TMS 374 - Citroen, Peugeot, Renault

POWER SUPPLY OF EMULATOR +5V!!!



Connection instructions – see manual for TMS 374 - Citroen, Peugeot, Renault

16. Daewoo 1




Connection instructions – see manual for Daewoo 1

17. Daewoo 2




Connection instructions – see manual for Daewoo 2

18. Fiat without CAN




Connection instructions – see manual for Fiat without CAN

19. Fiat with CAN - 5SF and 6F3 ECU




Connection instructions – see manual for Fiat CAN (5SF, 6F3)

20. Kia Sportage 2.0 TD



Connection instructions – see manual for Kia Sportage 2.0TD

21. Mercedes CR without CAN



Connection instructions – see manual for Mercedes CR without CAN infrared

22. Mercedes CR1 with CAN WSP



Connection instructions – see manual for Mercedes CR1 CAN WSP

23. Mercedes CR1 with CAN EZS



Connection instructions – see manual for Mercedes CR1 CAN EZS


24. Mercedes CR1 with CAN infrared



Connection instructions – see manual for


Mercedes CR1 CAN infrared

25. Mercedes CR2 with CAN WSP



Connection instructions – see manual for Mercedes CR2 CAN WSP

26. Mercedes ESL – steering wheel column lock emulator



Connection instructions – see manual for Mercedes ESL – steering wheel column lock emulator

27. Nissan NATS 4 and 5



Connection instructions – see manual for Nissan

28. Opel immo with HC05




Connection instructions – see manual for Opel

29. Renault without CAN




Connection instructions – see manual for Renault without CAN

30. Renault with CAN




Connection instructions – see manual for Renault with CAN

31. Renault Tacho with CAN - SCENIC II, ESPACE IV



Connection instructions – see manual for Renault Tacho CAN - Scenic II, Espace IV

32. Suzuki with X24C01 memory




Connection instructions – see manual for Suzuki with memory (OKI, X24C01)

33. Suzuki with OKI memory



Connection instructions – see manual for Suzuki with memory (OKI, X24C01)

- **Yamaha**



Connection instructions – see manual for
Yamaha

Seat Occupancy Sensor

The emulator needs to be connected to the plug under the passenger seat
instead of original seat occupancy sensor

There are 3 cables

+12V ACC


GND

DIGITAL SIGNAL


Before connecting the emulator, use multimeter to check signals on pins in the plug!

Connection instructions – see manual for
Seat occupancy sensor emulators

1. BMW



2. Mercedes




3. Mercedes




with installed child seat

4. Mercedes




without installed child seat

5. Mercedes




with installed child seat

6. Mercedes




without installed child seat

7. Mercedes




with installed child seat

8. BMW



without installed child seat

9. BMW




with installed child seat

10. Mini Cooper 2002-2005




without installed child seat

11. Mini Cooper 2002-2005




with installed child seat

12. Mazda




without installed child seat

13. Mazda




with installed child seat

14. Fiat Stilo




without installed child seat

15. Fiat Stilo




with installed child seat


16. Mercedes



17. Mercedes



18. Mercedes



Before connecting the emulator, it must be precisely insulated with insulation tape

Warning!!!

Due to possible construction changes of cars, check signals with multimeter in the ECU plug.

We state that we are the only authentic authors of this manual. We possess copyright of this publication. All rights reserved. Unauthorized copying, hiring, lending, public performance will be punished!!! Any trials of unauthorized copying, hiring, quoting prohibited!!! Both service and advertisement constitute copyright and they are the subject to the protection in accordance with the Act from 4th Feb. 1994 on Copyright and Related Laws (Statute Book no. 24 position 93) and protection on the basis of the Act from 8th June 1993 on combating an unfair competition (Statute Book no. 47 position 211)

www.edilock-bg.com

www.vag-info.com